


EXPLODED VIEW



REPLACEMENT PARTS LIST

Item No.	TE Part Number	Description	TEBQ 42G	TEBQ 42R
1	S26312-30WY	30" Front Hood Welded Assembly		
2	S26312-36WY	36" Front Hood Welded Assembly		
3	S26312-42WY	42" Front Hood Welded Assembly	1	1
4	S26312-54WY	54" Front Hood Welded Assembly		
5	S14128	Hood Bumper	4	4
6	S14304	Screw, Slotted, Hex Washer Head, .25-20 x .5, SS	4	4
7	S13258	Handle Endcap, Tri to Rod	2	2
8	S12315	Hood Handle (1.25D x 18 GA x 24)		
9	S12339	Hood Handle (1.25D x 18 GA x 30)		
10	S12316	Hood Handle (1.25D x 18 GA x 36)	1	1
11	S12347	Hood Handle (1.25D x 18 GA x 48)		
12	S15354	Thermometer	1	1
13	S14421	Basting Pan		1
14	S26349	Rotisserie Motor Housing		1
15	S16366Y	Rotisserie Motor with Sprocket		1
16	S26351	Cover, Rotis Motor Housing		1
17	S13932	Chain		1
18	S26311	Plate, Chain Cover		1
19	S16111	Electrical Cord	1	1
20	S14226	Hood Spring A-286	2	2
21	S12640	Elbow, 3/8 NPT x 3/8 MPT	1	1
22	S16240	Halogen Light Assembly	2	2
23	S16191	Bulb, Halogen Light	2	2
24	S16241	Cover Lens	2	2
25	S15108-50	Orifice #50 I.R. NG		
26	S15108-57	Orifice #57 I.R. LP		
27	S15108-48	Orifice #48 I.R. NG		1
28	S15108-56	Orifice #56 I.R. LP		1
29	S13865	Meat Holder Forks (pair), 9/16" spit rod		1
30	S13929-30	Warming Rack (30") (s/s)		
31	S13929-36	Warming Rack (36") (s/s)		
32	S13929-42	Warming Rack (42") (s/s)	1	1
33	S13929-54	Warming Rack (54") (s/s)		
34	S13928-30	Spit Rod (30") (s/s)		
35	S13928-36	Spit Rod (36") (s/s)		
36	S13928-42	Spit Rod (42") (s/s)		1
37	S13928-54	Spit Rod (54") (s/s)		
38	S16112	Strain Relief	1	1
39	S14194	Spring Stand Off	2	2
40	S12112	Hood Switch Striker	1	1
41	S14232	Self-locking Retaining Ring	3	3
42	S21756	Bracket, Hood Switch	1	1
43	S16194	Switch, Hood, Carling P2267T-ID-RD	1	1
44	S26325-30	Front Inner Air Baffle (30")		
45	S26325-36	Front Inner Air Baffle (36")		
46	S26325-42	Front Inner Air Baffle (42")	1	1
47	S26325-54	Front Inner Air Baffle (54")		
48	S26323-30	Lower Front Heat Shield (30")		
49	S26323-36	Lower Front Heat Shield (36")		
50	S26323-42	Lower Front Heat Shield (42")	1	1
51	S26323-54	Lower Front Heat Shield (54")		
52	S26336-30	Front Heat Shield (30")		
53	S26336-36	Front Heat Shield (36")		
54	S26336-42	Front Heat Shield (42")	1	1
55	S26336-54	Front Heat Shield (54")		
56	S26354Y	Transformer Bracket Assembly	1	1
57	S16385	Transformer	1	1
58	S26331-30WY	Front Panel Weld Assembly (30") G Model		
59	S26316-30WY	Front Panel Weld Assembly (30") R Model		
60	S26331-36WY	Front Panel Weld Assembly (36") G Model		
61	S26316-36WY	Front Panel Weld Assembly (36") R Model		
62	S26331-42WY	Front Panel Weld Assembly (42") G Model	1	
63	S26316-42WY	Front Panel Weld Assembly (42") R Model		1
64	S26316-54WY	Front Panel Weld Assembly (54")		
65	S13270	Light Bezel Housing Assembly	4	4
66	S13224	Lens, Light Bezel	4	4
67	S13226	Rubber Retention Ring, Light Bezel	4	4
68	S19146	Label, Switches, 110V-12V	1	1
69	S16365	Switch, 110V, Rotis		1
70	S16196	Switch, 12V, Lights	1	1
71	S13203	Emblem, Twin Eagles	1	1



REPLACEMENT PARTS LIST - CONTINUED

Item No.	TE Part Number	Description	TEBQ 42G	TEBQ 42R	
72	S13235Y	Knob Assembly	4	4	
73	S15303	Regulator, NG	1	1	
74	S15302	Regulator, LP	1	1	
75	S13301	U6-Burner	3	3	
76	S13350	U5-Burner			
77	S13345	Sear Burner Assembly (Optional Addition)	1	1	
78	S13144	Mesh Screen for Sear Burner	1	1	
79	S16322	Hot Surface Igniter, Rotisserie		1	
80	S26334	I.R. Igniter Hood - LH		1	
81	S26377	I.R. Igniter Hood - RH			
82	S26306	Bracket, Warming Rack Stowed	2	2	
83	S14340	Hood Sleeve	2	2	
84	S14303	.250 X 1.750 SS Hex Head Screw	2	2	
85	S26307	Bracket, Warming Rack HI/LOW Position	2	2	
86	S26310	Spacer Plate, Rotis Rollers		4	
87	S14420	Roller Bearing		4	
88	S21750WY	Flash Tube Assembly	3	3	
89	S16386	Terminal Block	1	1	
90	S26372	Terminal Block Cover	1	1	
91	S16321	Igniter, Main Burners	3	3	
92	S26344	Ignition Cover	3	3	
93	S21765WY	Flash Tube Assembly (Optional Sear Burner Only)	1	1	
94	S26326-30	Lower Front Air Baffle (30")			
95	S26326-36	Lower Front Air Baffle (36")			
96	S26326-42	Lower Front Air Baffle (42")	1	1	
97	S26326-54	Lower Front Air Baffle (54")			
98	S15110-41	Orifice, #41 NG (Main Burner)	3	3	
99	S15110-53	Orifice, #53 LP (Main Burner)	3	3	
100	S15121	Microswitch, Valve Burner	3	3	
101	S12601	Elbow, 375CC x 125FIP		1	
102	S15149Y	Valve Burner	3	3	
103	S12734	Manifold (30")			
104	S12736	Manifold (36")			
105	S12735	Manifold (42")	1	1	
106	S12745	Manifold (54")			
107	S26319-30	Drip Pan Assembly (for Grills with Hidden Rotis)			
108	S26319-36	Drip Pan Assembly (for Grills with Hidden Rotis)			
109	S26319-42	Drip Pan Assembly (for Grills with Hidden Rotis)		1	
110	S26319-54	Drip Pan Assembly (for Grills with Hidden Rotis)			
111	S12606	Plug, 1/8	*	*	
112	S21761Y	5" Briquette Tray Assembly			
113	S21759Y	10" Briquette Tray Assembly			
114	S22735Y	Smoker Box Assembly (30", 42", 54")	1	1	
115	S22737Y	Smoker Box Assembly (36")			
116	S21752Y	6" Briquette Tray Assembly	2	2	
117	S21753Y	12" Briquette Tray Assembly			
118	S21743	Zone Divider			
119	S13875	10 9/16" SS Hex Grate			
120	S13802	12" SS Hex Grate			
121	S13801	13" SS Hex Grate			
122	S13330	I.R. Burner Small			
123	S13331	I.R. Burner Large			
124	S26300-30	Rear Hood Cover (30")			
125	S26300-36	Rear Hood Cover (36")			
126	S26300-42	Rear Hood Cover (42")			
127	S26300-54F	Rear Hood Cover (54")			
128	S15151Y	Rotis Valve Burner			
129	S12665	Plug, Hex Socket, 1/4 NPT			
130	S26332-30	Drip Pan Assembly (30") (for G Model)			
131	S26332-36	Drip Pan Assembly (36") (for G Model)			
132	S26332-42	Drip Pan Assembly (42") (for G Model)			
133	S13267	Rotis Bezel Housing Assembly			
134	S26311	Plate, Chain Cover			
135	S26807Y	Sprocket Assembly			
Non-Shown Parts					
	S13129-12	Briquettes (12 pack)			
	S16391	12V Harness			
	S16392	110V Harness			
	S16006	8" Bezel Loop Harness			
	S16007	14" Bezel Loop Harness			

